Riser Installation Guide

Included Hardware:

- (4) 7/8" length 3/8”- 16 hex screws
- (4) 3/8" locknuts
- (8) 3/8" flat washers

Recommended Tools:

- 9/16” socket driver and box wrench
- 3/8” socket driver and box wrench

Installing Riser to a Floor Plate:

- Remove the front cover of the riser by unscrewing the two ¼”-20 ½” screws with the 3/8” wrench
- Align Riser installation holes with the floor plate
- Install the four 7/8” length 3/8”- 16 hex screws
- Screw the front cover back on with the two ¼”-20 ½” screws







Installing Riser to Industrial Portal:

- Remove the front cover of riser by unscrewing the two ¼”-20 ½” screws with 3/8” wrench
- Remove quick access panel from the Industrial Portal by unscrewing the six ¼”-20 ½” screws
- Align Riser installation holes with the Industrial Portal
- Install the four 7/8” length 3/8”- 16 hex screws